


UGP-24V PC1 S/S PARTS DIAGRAM AND LIST



PARTS LIST

Item #	Description	Part #
1	Backsplash	UGP-G24H08-011600
2	Backsplash inner plate	UGP-G24H08-011700
3	Backsplash cover	UGP-G24H08-011500
4	75 burner	UGP-G20A02-040100
5	130 burner	UGP-G20A02-040300
6	100 burner	UGP-G20A02-040200
7	55 burner	UGP-G20A02-040000
8	Pan support (left)	UGP-G24C05-021300
9	Pan support (right)	UGP-G24C05-021600
10	Cooktop	UGP-G24H08-020100
11	Cavity heat insulation plate	UGP-C24B01-074500
12	Regulator adaptor	UGP-G24G02-034200
13	Regulator	UGP-G20C01-034003
14	Regulator support	UGP-G24G02-034500
15	Gas pipe	UGP-G24H08-030700
16	Thermostat	UGP-G20C02-030619
17	Valve-0.50	UGP-G20D02-030535
18	Valve-0.81	UGP-G20D02-030533
19	Valve-0.95	UGP-G20D02-030534
20	Control panel inside panel	UGP-G24H08-030400
21	Control panel insulation cotton	UGP-G24H08-036000
22	Control panel	UGP-G24H08-030300
23	Control panel connection plate (right)	UGP-G20C01-022200
24	Switch ASM	UGP-G24H08-170200
25	Knob #19	UGP-G20A19-030100-09
26	Knob ring #6	UGP-G20A06-030200-10
27	Knob-spring	UGP-G20A19-030300
28	Control panel strip	UGP-G24H08-214500
29	Control panel connection plate (left)	UGP-G20C01-022100
30	G1/2 gasket	UGP-G20A01-210500
31	Door top cover	UGP-G24B01-101401
32	Door glass shockproof	UGP-G20A01-103300
33	LOWE Inner glass door	UGP-G24H08-100500
34	LOWE Door inside window	UGP-G24H08-101100
35	Hinge Support(right)	UGP-G20B01-101300
36	Door frame (up)	UGP-G24H08-020000
37	SUS Handle	UGP-G24B11-101900
38	Handle gasket	UGP-G20B02-100700
39	Outer door glass	UGP-G24H08-100400-05
40	Door inside glass support(right)	UGP-G20B01-100900
41	Door frame (down)	UGP-G24H08-020001
42	Unique Logo with Pins	UGP-DWWJ03002
43	LOGO gasket	UGP-G24F08-100800
44	Hinge Support(left)	UGP-G20B01-101200
45	Door hinge	UGP-G20B01-110003

PARTS LIST

Item #	Description	Part #
46	Door inside glass support(left)	UGP-G20B01-100800
47	SUSHandle	UGP-G24B11-101900
48	Drawer outside plate	UGP-G24H08-120100
49	Drawer cushion gasket	UGP-G20A01-120900
50	Drawer inside plate	UGP-G24C02-120200-04
51	Drawer plate	UGP-G24C03-120500-02
52	Sliding rail component	UGP-G20A01-120700
53	Front plate	UGP-G24C01-070102
54	Front plate-Beam	UGP-G24A01-070200
55	Front plate retaining strip	UGP-G24B01-214500
56	Cavity sealing strip-1	UGP-G24G02-071200
57	Cavity sealing strip-2	UGP-G24C01-071200
58	Cavity right plate	UGP-G20A01-070500
59	Door hinge plate	UGP-G20C01-111100
60	Oven feet mounting plate	UGP-G20A01-071100
61	Oven feet	UGP-G20C01-071500
62	Burner mounting plate	UGP-G24C01-072100
63	Anti-tip bracket	UGP-G20A01-212500
64	Oven burner assembly	UGP-G20B01-080100
65	Oven burner plate	UGP-G20A01-080900
66	Oven burner spark plug230	UGP-G20C01-170502
67	Bakeware	UGP-G24A01-070700
68	Roasted net	UGP-G24H08-071900
69	Broil tray	UGP-G20C01-215000
70	Broil grill	UGP-G20C01-215100
71	Back plate	UGP-G24C01-070305
72	(2.5Kg) Weight Block	UGP-G20A01-210200
73	Regulator fixed part	UGP-G20C01-034500
74	120V Ignitor	UGP-G20C01-170106
75	Power fixed parts	UGP-G20A01-160200
76	(18AWG) Power Cord	UGP-G20A07-160105
77	Cavity left plate	UGP-G20A01-070400
78	T=0.5 Side plate	UGP-G20C01-071002
79	120VTemperature fan	UGP-G20A01-091502
80	Back insulation cotton	UGP-G24C01-072900
81	Temperature fan baffle	UGP-C36A01-073100
82	Baffle plate	UGP-G24C01-072000
83	cooktop back connection plate	UGP-G20C01-022000
84	Support between wall and unit	UGP-G20C01-212600
85	120V 15WLamp	UGP-G20C01-180101
86	Top burner assembly	UGP-G20C01-090100
87	Top burner plate	UGP-G20C01-090300
88	Top burner infrared network	UGP-G20C01-090500
89	Grill burner spark plug 540	UGP-G20C01-170500
90	Cavity top plate	UGP-G24C01-070600

PARTS LIST

Item #	Description	Part #
91	Chimney (with hole)	UGP-G20C01-074101
92	Chimney (no hole)	UGP-G20C01-074100
93	Diversion Plate	UGP-G20C01-075000
94	NG Injector(0.73)	UGP-G20A01-021208
	LPG Injector(0.53)	UGP-G20A01-021200
	NG Injector (1.0)	UGP-G20A01-021206
	LPG Injector(0.68)	UGP-G20A01-021201
	NG Injector(1.3)	UGP-G20A01-021213
	LPG Injector(0.9)	UGP-G20A01-021203
	NG Injector(1.5)	UGP-G20A01-021227
	LPG Injector(1.0)	UGP-G20A01-021206
	Top burner NG injector (1.24)	UGP-G20A01-021212
	Top burner LPG injector (0.8)	UGP-G20A01-021202
	Oven burner NG injector (1.3)	UGP-G20A01-021213
	Oven burner LPG injector(0.82)	UGP-G20A01-021204
95	Nozzle mount part	UGP-G20A01-021100
96	Temperature fan cover	UGP-G36A01-091700
97	left/back pipe assembly	UGP-G24H08-022300
	right/back pipe assembly	UGP-G24H08-022600
	left/frontright/front pipe assembly	UGP-G24F08-022500
	Oven burner asm-burner pipe	UGP-G20C01-023100
	Top burner asm-burner pipe	UGP-G20C01-023300
98	burner cup mounting plate	UGP-G24C01-024200
99	Spark plug 1100	UGP-G24A01-170401
	Spark plug 1050	UGP-G20A01-170406
	Spark plug 900	UGP-G20A01-170405
	Spark plug 680	UGP-G20A01-170404
100	Thermocouple 300mm	UGP-G20A01-030900
	Thermocouple 500mm	UGP-G20A01-030901
	Thermocouple	UGP-G24A01-031000
101	Aluminum foil Ceramic Heater	UGP-G20A01-300500
102	Transformer	UGP-G20A01-106600
103	Transformer fixed plate	UGP-G24C01-191000
104	Spark plug-retainer	UGP-G20A01-170600
105	Wire conectors	UGP-G20A01-160300
106	Door glass support	UGP-G20A10-100900
107	Harness	UGP-G24H08-180300
108	Cavity heat insulation cotton	UGP-G24A01-070800
109	Thermostat probe retaining clip	UGP-G20A01-031100