

---

# UNIQUE®

2245 Wycroft Road #5, Oakville, Ontario Canada L6L 5L7  
Ph: 905-827-6157 Toll Free: 1-877-427-2266 Fax: 905-827-2027

[www.UniqueOffGrid.com](http://www.UniqueOffGrid.com)

## UNIQUE UGP-6F Parts Guide 2014




"Personal Service & Knowledge  
makes us Unique"

---

Parts Diagram and List

UNIQUE UGP-6F EXPLODED DIAGRAM



## UNIQUE UGP 6F – Parts List

<b>No.</b>	<b>Item</b>	<b>Code</b>
1	Cooling unit	UGP-DL20003111
2	Insulation cover	UGP-DL20001265
3	Cap	UGP-DL22501173
4	Baffle	UGP-DL27501007
5	Baffle holder	UGP-DL20001268
6	Iron hinge	UGP-DL00002014
7	Hinge cover(top)	UGP-DL00009180
8	Hinge cover(bottom)	UGP-DL00009181
9	Screw	UGP-DL00003005
10	Flat washer	UGP-DL00003022
11	Spring Washer	UGP-DL00003018
12	Heat sink	UGP-DL20001059
13	Heat sink panel	UGP-DL20001161
14	Cabinet	N/A
15	Freezer Lid	UGP-DL90000014
16	Control label	UGP-DL27501241
17	Rear cabinet support	UGP-DL20001280
18	Cabinet support	UGP-DL20001256
19	Foot support	UGP-DL20001281
20	Engine room support	UGP-DL17001047
21	Foot	UGP-DL14502351
22	Handle	UGP-DL11801034
23	Handle Cover	UGP-DL11801055
24	Flame indicator	UGP-DL18301013
25	Lock	UGP-DL00005106
26	Lock latch	UGP-DL00005051
27	Key	UGP-DL00005052
28	Basket	UGP-DL20001262
29	Bolt	UGP-DL00003042
30	Spring Washer	UGP-DL00003017
31	Flat Washer	UGP-DL00002011
32	Inlet nipple cap	UGP-DL22001160
33	Nut for safety valve	UGP-DL00003136
34	Connector bracket	UGP-DL10001264

<b>No.</b>	<b>Item</b>	<b>Code</b>
35	Gas connector	UGP-DL10001267
36	Battery ignitor	UGP-DL18301371
37	Connection wire	UGP-DL22501187
38	Push button switch	UGP-DL18301372
39	Battery	UGP-DL00013681
40	Electrode	UGP-DL27501257
41	Bracket	UGP-DL18301015
42	Nut	UGP-DL10001407
43	Seal ring	UGP-DL10001136
44	Pipe	UGP-DL20001271
45	Pipe	UGP-DL18301123
46	Safety valve	UGP-DL18301005
47	Spring	UGP-DL10001145
48	Button	UGP-DL18301034
49	Connector	UGP-DL10001406
50	Connector	UGP-DL10001405
51	Thermocouple	UGP-DL10001349
52	Connector	UGP-DL22001180
53	Thermocouple wire	UGP-DL10001351
54	Connector	UGP-DL10001114
55	Nut	UGP-DL18301029
56	Thermostat	UGP-DL10001430
57	Knob	UGP-DL18301033
58	Thermostat bracket	UGP-DL18301012
59	Checkpoint assembly	UGP-DL27501365
59-1	Check point plug	UGP-DL22501206
59-2	Washer	UGP-DL00009306
59-3	Check point connector	UGP-DL10001501
59-4	Check point body	UGP-DL10001498
59-5	Nut	UGP-DL10001474
59-6	Injector	UGP-DL10001469
60	Burner assembly	UGP-DL10001496
60-1	Burner bracket	UGP-DL22502507
60-2	Burner tube support	UGP-DL10001476
60-3	Burner tube	UGP-DL10001142
61	Burner cover assy	UGP-DL22502506
61-1	Burner cover	UGP-DL22502508
61-2	Cover window	UGP-DL10001186
62	Lamp	UGP-DL00013598

<b>No.</b>	<b>Item</b>	<b>Code</b>
63	Connection wire	UGP-DL27501292
64	Power cord	UGP-DL10001252
65	Grounding wire	UGP-DL10001056
66	Heater	UGP-DL27501293
67	Rotary switch	UGP-DL10001213
68	Bracket	UGP-DL10001271
69	Bracket	UGP-DL18301201