


# UGP -36CR



## UGP-36CR RANGE PARTS LIST

ITEM#	DESCRIPTION	PART#
1	Backsplash Mending Plate <b>UGP-36CR</b>	<b>UGP-SNG122000403049</b>
2	Chimney <b>UGP-36CR</b>	<b>UGP-SNG182000200051</b>
3	Gas Inlet Pipe <b>UGP-36CR</b>	<b>UGP-SNG142002000099</b>
4	Back Panel <b>UGP-36CR</b>	<b>UGP-SNG122000203014</b>
5	Protection Cap <b>UGP-36CR</b>	<b>UGP-SNG160400000084</b>
6	Cooktop Rear Support <b>UGP-36CR</b>	<b>UGP-SNG122000203005</b>
7	Fan Baffle Plate <b>UGP-36CR</b>	<b>UGP-SNG122000103021</b>
8	Pulse Ignitor <b>UGP-36CR</b>	<b>UGP-SNG142001000001</b>
9	Pulse Ignitor Support <b>UGP-36CR</b>	<b>UGP-SNG122000103027</b>
10	Wire Junction Box <b>UGP-36CR</b>	<b>UGP-SNG122000103018</b>
11	Safety Valve <b>UGP-36CR</b>	<b>UGP-SNG142001000011</b>
12	Safety Valve Support <b>UGP-36CR</b>	<b>UGP-SNG122000103030</b>
13	Gas Regulator Cover <b>UGP-36CR</b>	<b>UGP-SNG122000103029</b>
14	Gas Regulator <b>UGP-36CR</b>	<b>UGP-SNG142001000012</b>
15	Rear Heatshield Panel <b>UGP-36CR</b>	<b>UGP-SNG122000203009</b>
16	Left Side Panel <b>UGP-36CR</b>	<b>UGP-SNG122000103005</b>
17	Left Heatshield Panel <b>UGP-36CR</b>	<b>UGP-SNG122000103017</b>
18	Oven Light <b>UGP-36CR</b>	<b>UGP-SNG142001000023</b>
19	Oven Inner Side Panel <b>UGP-36CR</b>	<b>UGP-SNG122000102003</b>
20	Power Cord <b>UGP-36CR</b>	<b>UGP-SNG143101000274</b>
21	Base Plate <b>UGP-36CR</b>	<b>UGP-SNG122000203004</b>
22	Bottom Heatshield <b>20/24/24/30CR ON1/EC</b>	<b>UGP-SNG122000103010</b>
23	Oven Inner Back Panel <b>UGP-36CR</b>	<b>UGP-SNG122000203001</b>

## UGP-36 RANGE PARTS LIST

ITEM#	DESCRIPTION	PART#
24	Convection Fan <b>UGP-36CR</b>	<b>UGP-SNG142001000025</b>
25	U-Shape Oven Burner <b>UGP-30G/30 CR EC</b>	<b>UGP-SNG142002000100</b>
26	Oven Door Hinge Bracket <b>UGP-36CR</b>	<b>UGP-SNG142002000156</b>
27	U-Shape Burner Heat Reflector <b>UGP-36CR</b>	<b>UGP-SNG122000103026</b>
28	Convection Fan Cover <b>UGP-36CR</b>	<b>UGP-SNG122000103002</b>
29	Adjustable Feet <b>UGP-36CR</b>	<b>UGP-SNG142002000037</b>
30	Oven Door Seal <b>UGP-36CR</b>	<b>UGP-SNG142003000011</b>
31	Oven Front Plate <b>UGP-36CR</b>	<b>UGP-SNG122000205002</b>
32	U-shape Burner Orifice (2.13) NG <b>UGP-36CR</b>	<b>UGP-SNG142002000105</b>
	U-shape Burner Orifice (1.40) LPG <b>UGP-36CR</b>	<b>UGP-SNG142002000106</b>
33	Oven Door Hinge (Left) <b>UGP-36CR</b>	<b>UGP-SNG142002000113</b>
34	Oven Floor <b>UGP-36CR</b>	<b>UGP-SNG122000202004</b>
35	Oven Rack <b>UGP-36CR</b>	<b>UGP-SNG142002000092</b>
36	Kickplate White <b>UGP-36CR</b>	<b>UGP-SNG122000406062</b>
	Kickplate Black <b>UGP-36CR</b>	<b>UGP-SNG122000406063</b>
	Kickplate Turquoise <b>UGP-36CR</b>	<b>UGP-SNG122000406051</b>
	Kickplate Light Green <b>UGP-36CR</b>	<b>UGP-SNG122000406064</b>
37	Oven Door ASSY White <b>UGP-36CR</b>	<b>UGP-SNG182000400082</b>
	Oven Door ASSY Black <b>UGP-36CR</b>	<b>UGP-SNG182000400083</b>
	Oven Door ASSY Turquoise <b>UGP-36CR</b>	<b>UGP-SNG182000400064</b>
	Oven Door ASSY Light Green <b>UGP-36CR</b>	<b>UGP-SNG182000400084</b>

## UGP-36CR RANGE PARTS LIST

ITEM#	DESCRIPTION	PART#
38	Oven Door Handle ASSY White <b>UGP-36CR</b>	<b>UGP-SNG142002000340</b>
	Oven Door Handle ASSY Black <b>UGP-36CR</b>	<b>UGP-SNG142002000351</b>
	Oven Door Handle ASSY Turquoise <b>UGP-36CR</b>	<b>UGP-SNG142002000353</b>
	Oven Door Handle ASSY Light Green <b>UGP-36CR</b>	<b>UGP-SNG142002000352</b>
39	Top Burner Knob White <b>UGP-36CR</b>	<b>UGP-SNG142002000355</b>
	Top Burner Knob Black <b>UGP-36CR</b>	<b>UGP-SNG122000406053</b>
40	Knob Bezel <b>UGP-36CR</b>	<b>UGP-SNG142002000016</b>
41	Oven Knob White <b>UGP-36CR</b>	<b>UGP-SNG142002000354</b>
	Oven Knob Black <b>UGP-36CR</b>	<b>UGP-SNG122000404054</b>
42	Control Panel White <b>UGP-36CR</b>	<b>UGP-SNG122000404074</b>
	Control Panel Black <b>UGP-36CR</b>	<b>UGP-SNG122000404075</b>
	Control Panel Turquoise <b>UGP-36CR</b>	<b>UGP-SNG122000404050</b>
	Control Panel Light Green <b>UGP-36CR</b>	<b>UGP-SNG122000404076</b>
43	Toggle Switch <b>UGP-36CR</b>	<b>UGP-SNG142001000153</b>
44	Indicator Lamp <b>UGP-36CR</b>	<b>UGP-SNG142001000007</b>
45	Control Panel Frame S/S <b>UGP-36CR</b>	<b>UGP-SNG122000204001</b>
46	Oven Door Hinge (Right) <b>UGP-36CR</b>	<b>UGP-SNG142002000116</b>
47	Oven Thermostat <b>UGP-36CR</b>	<b>UGP-SNG142001000009</b>
48	Oven Inner Side Panel (Right) <b>UGP-36CR</b>	<b>UGP-SNG122000102004</b>
49	Right Side Panel <b>UGP-36CR</b>	<b>UGP-SNG122000103036</b>

## UGP-36CR RANGE PARTS LIST

ITEM#	DESCRIPTION	PART#
50	Right Heatshield Panel <b>UGP-36CR</b>	<b>UGP-SNG122000103006</b>
51	Cooktop Front Support <b>UGP-36CR</b>	<b>UGP-SNG122000203006</b>
52	Oven Rack Support <b>UGP-36CR</b>	<b>UGP-SNG142002000089</b>
53	L-Shape Burner NG Orifice <b>UGP-36CR</b>	<b>UGP-SNG142002000107</b>
	L-Shape Burner LPG Orifice <b>UGP-36CR</b>	<b>UGP-SNG142002000108</b>
54	L-Shape Burner <b>UGP-36CR</b>	<b>UGP-SNG142002000102</b>
55	L-Shape Burner Heat Reflector <b>UGP-36CR</b>	<b>UGP-SNG122000102010</b>
56	Oven Ceiling <b>UGP-36CR</b>	<b>UGP-SNG122000202001</b>
57	Gas Valve Bracket <b>UGP-36CR</b>	<b>UGP-SNG122000204022</b>
58	Microswitch <b>UGP-36CR</b>	<b>UGP-SNG182000400065</b>
59	Top Dual Burner Right Front (20000 BTU) ASSY <b>UGP-36CR</b>	<b>UGP-SNG182000400089</b>
	Top Burner Left Front (15000 BTU) ASSY <b>UGP-36CR</b>	<b>UGP-SNG182000400088</b>
	Top Burner Right Rear (12000 BTU) ASSY <b>UGP-36CR</b>	<b>UGP-SNG182000400087</b>
	Top Burner Centre Rear (9000 BTU) ASSY <b>UGP-36CR</b>	<b>UGP-SNG182000400086</b>
	Top Burner Centre Front (6000 BTU) ASSY <b>UGP-36CR</b>	<b>UGP-SNG182000400085</b>
60	N/A	<b>UGP-SNG182000400068</b>
61	N/A	<b>UGP-SNG182000400069</b>
62	Cast Iron Grate (each) <b>UGP-36CR</b>	<b>UGP-SNG142002000319</b>

## UGP-36CR RANGE PARTS LIST

ITEM#	DESCRIPTION	PART#
63	Retro Backsplash White ASSY <b>UGP-36CR</b>	<b>UGP-SNG122000403052W</b>
	Retro Backsplash Black ASSY <b>UGP-36CR W</b>	<b>UGP-SNG122000403052B</b>
	Retro Backsplash Turquoise ASSY <b>UGP-36CR W</b>	<b>UGP-SNG122000403052T</b>
	Retro Backsplash Light Green ASSY <b>UGP-36CR W</b>	<b>UGP-SNG122000403052LG</b>
64	Slim Design Backsplash <b>UGP-CR/EC all colors</b>	<b>UGP-SNG122000403047</b>
65	Front Right Burner Gas Pipe #10 <b>UGP-36CR</b>	<b>UGP-SNG142002000078</b>
	Front Right Burner Gas Pipe #9 <b>UGP-36CR</b>	<b>UGP-SNG142002000077</b>
	Rear Centre Burner Gas Pipe #7 <b>UGP-36CR</b>	<b>UGP-SNG142002000075</b>
	Front Centre Burner Gas Pipe #8 <b>UGP-36CR</b>	<b>UGP-SNG142002000076</b>
	Rear Left/Right Burner Gas Pipe #5 <b>UGP-36CR</b>	<b>UGP-SNG142002000073</b>
	Front Left Burner Gas Pipe #6 <b>UGP-36CR</b>	<b>UGP-SNG142002000074</b>
66	Gas Manifold <b>UGP-24/30CR/EC</b>	<b>UGP-SNG142002000097</b>
67	24" (right) Cooktop <b>UGP-36CR</b>	<b>UGP-SNG122000101002</b>
68	Top Burner Mount Bracket <b>UGP-36CR</b>	<b>UGP-SNG122000103020</b>
69	12" (Left) Cooktop <b>UGP-36CR</b>	<b>UGP-SNG122000101001</b>
70	Upper Heatshield <b>UGP-36CR</b>	<b>UGP-SNG122000203008</b>

## UGP-36CR RANGE PARTS LIST

<b>ITEM#</b>	<b>DESCRIPTION</b>	<b>PART#</b>
71	Hot Surface Ignitor (HSI) <b>UGP-36CR</b>	<b>UGP-SNG142002000019</b>
NS	LPG Orifice Kit <b>UGP-36CR</b>	<b>UGP-SNG182000400095</b>
NS	NG Orifice Kit <b>UGP-36CR</b>	<b>UGP-SNG182000200090</b>
NS	Ignition Electrode for Dual Burner (20000 BTU) <b>UGP-36CR</b>	<b>UGP-SNG1420020000157</b>